NURSERY RHYMES
Software Module
Version 1.0
By STAR, Inc.

The "Nursery Rhymes" software module allows RB5X to recite seven different nursery rhymes at the press of a bumper!

Age Level
Children of all ages and adults can use and enjoy the "Nursery Rhymes" software module.

Operation

1. Make sure RB5X is switched off.

2. Insert the software module into the socket on the RB5X's interface panel, making sure the guide marks on the socket and on the module match up. Push the module firmly into the socket.

3. Check the label on your "Nursery Rhymes" module and set the module switch located to the right of the socket to the appropriate position (2K or 4K).

4. Switch RB5X on (the top of the rocker switch on the interface panel is pushed in). The five center LEDs begin flashing and the robot says, "Hello little friend, my name is RB the happy robot. Press one of my bumpers and I will say a nursery rhyme for you." If this does not happen, check to be sure the software module is installed correctly, that the robot is adequately charged, and that the switch located to the right of the module socket is set to the proper position. If the LEDs still do not flash, check the "Troubleshooting" section of the RB5X Reference Manual.

5. Press the robot's bumpers to hear one of the following five nursery rhymes:
Jack and Jill Little Jack Horner
Little Miss Muffet
One, Two, Buckle My Shoe
Peter, Peter, Pumpkin Eater
Mary Had a Little Lamb
Little Boy Blue

RB5X selects rhymes to recite at random.

6. Occasionally the robot will respond to a bumper press with, "This sure is fun to do!" or "Ooh, that ticklesl" rather than with one of the nursery rhymes.

7. Be sure RB5X is switched off before you remove the "Nursery Rhymes" software module.